

Sunbeam

Steam Pro Compact

Professional Ironing System

Instruction Booklet
SR8200

Please read these instructions carefully
and retain for future reference.



Contents

Sunbeam's Safety Precautions	1
Features of your Steam Pro Compact	2
Using your professional ironing system	4
Care and cleaning	6
Ironing guide	7
Ironing chart	8

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich daß die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید کہ احتیاطهای بالا حتماً درك بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR PROFESSIONAL IRONING SYSTEM.

- Do not remove the boiler cap during use, as the unit is under pressure and there is a danger of scolding. Allow the unit to cool for 5 minutes before opening.
- Do not leave a hot iron within reach of children. If they come into contact with a hot iron it could lead to serious burns!
- Iron only on an ironing board.
- An iron takes approximately 30 minutes to cool down.
- Do not wind the cord around the soleplate
- Do not leave the iron unattended while it is plugged into the power outlet.
- Always unplug the iron from the power outlet before filling or emptying the water tank.

Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- Close supervision is necessary when your appliance is being used near children or infirm persons.
- Never leave an appliance unattended while in use.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- For safety reasons and to avoid maintenance by unskilled persons, some appliances are 'sealed' using tamperproof screws. Such appliances should always be returned to the nearest Sunbeam Appointed Service Centre for adjustment or repair if required.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been dropped or damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Features of your Steam Pro Compact

Iron thermostat light


The iron thermostat light illuminates to indicate that the iron soleplate is heating, and goes out when it has reached the temperature selected on the temperature dial. The thermostat light cycles on and off during ironing as the iron soleplate maintains the selected temperature.

Boiler cap


The easy-fill boiler holds 1 litre water.

Iron rest

Place the iron on the heat resistant iron rest during ironing.



professional ironing system



Steam release button

Press and hold the steam release button to produce a constant stream of high-powered steam to reduce your ironing time and effort. Steam will not be emitted from the iron when the steam release button is not depressed.

Variable temperature dial

The variable temperature dial adjusts the temperature of the iron soleplate, allowing you to select the desired temperature for each garment.

Boiler thermostat light

The boiler thermostat light illuminates to indicate that the boiler is heating, and goes out when the temperature is sufficient to generate steam. When the light stays illuminated, the boiler has run out of water.

Steam ready indicator

The steam ready indicator illuminates to indicate that the steam function is ready to use.

Iron and boiler on/off button

This switch controls the internal boiler and the iron soleplate.

Using your professional ironing system

Before first use

Remove any adhesive stickers, plastic covers or cardboard sleeves from the soleplate. Remove any remaining adhesive by rubbing the soleplate with a cloth dampened with methylated spirits.

Filling the boiler with water when cold

Before filling the boiler with water, ensure that the power is turned off and the plug is removed from the power outlet.

Unscrew the boiler cap. Using the funnel provided, fill the boiler with 1 litre of water. Replace the boiler cap and tighten.

Note: The non-corrosive stainless steel boiler has been designed to allow you to use tap water in your professional ironing system. However, in very hard water areas, Sunbeam recommends the use of distilled or demineralised water. For best performance, we recommend the use of Sunbeam Water Demineraliser, available from Sunbeam Service Centres and selected retailers. This produces up to 30 litres of demineralised water.

Caution: Do not fill the boiler with fabric conditioners, starches, scented water, or any other solution, as these will damage the steam mechanism. Do not use contaminated water.

Using your professional ironing system

1. Insert the plug into a 230/240V power outlet and turn the power on.
2. Depress the iron and boiler on/off button to turn the appliance on.

Note: when turned on for the first time your new iron may give off vapours for up to 10 minutes. This is due to the initial heating of the materials used. It is safe, not detrimental to the performance of the iron and will not reoccur.

3. Turn the temperature dial on the iron to the desired setting. The thermostat light will illuminate to indicate that the iron is heating. It will go out once the iron has reached the selected temperature.

Note: when changing the temperature dial from a higher setting to a lower setting, allow the iron to cool for at least 2 minutes before continuing ironing.

4. The green steam ready indicator will turn on and off several times during the first minute. Once it comes on and stays illuminated, you can commence ironing. Before using steam on a garment, direct a shot of steam into the air to release any remaining condensation.

Using your professional ironing system continued

5. Press and hold the steam release button to iron with steam. To dry iron, do not press the steam release button. Both the steam ready indicator and the boiler thermostat light will cycle on and off during ironing as the ironing system maintains the selected steam pressure and temperature level.

Note: To prevent water dripping from the soleplate, only use the steam function on higher temperature settings (●● and above).

6. Once you have finished ironing, switch the iron and boiler off by pressing the on/off button. Switch the power off at the power outlet and remove the plug. Wait for the iron to cool completely before storing. Do NOT empty the boiler.

Filling the boiler when hot

When pressing the steam release button fails to emit steam and the boiler thermostat light stays illuminated, the boiler has run out of water.

To refill the boiler:

1. Press the on/off button to switch the appliance off.
2. Turn the power off and remove the plug from the power outlet.

3. Wait a few minutes for the boiler to cool, then loosen the cap slowly to release any remaining steam in the boiler.

4. Unscrew and remove the cap completely.

5. Wait a few minutes before slowly refilling the boiler using the funnel provided.

Caution: Use extreme caution when filling the boiler, as adding cold water into the hot boiler will immediately produce steam which can scald skin.

6. Replace the boiler cap and tighten.

7. Follow steps 1 to 4 on page 4 to recommence ironing.

Storage

If you do not intend to use your professional ironing system for several weeks, wait until the appliance has cooled completely, then unscrew the boiler cap and empty the remaining water from the boiler before storing.

Care and cleaning

To clean the exterior of your appliance, wipe over with a damp soft cloth and wipe dry.

Do NOT use harsh abrasives, chemical cleaners or solvents to clean the exterior of your appliance, as these will damage the surface.

To clean the stainless steel soleplate, use a stainless steel or metal cleaner and rub gently with a damp cloth and wipe dry.

Do not use scouring pads, abrasives or harsh cleaners to clean your stainless steel soleplate as these will scratch and damage the surface.

Ironing guide

Selecting the ironing temperature.

Always read garment labels and follow the manufacturer's ironing instructions. Refer to the Ironing Chart for temperature recommendations.

Hints for easier ironing

- Sort articles to be ironed according to the type of fabric. This will reduce the need to adjust the temperature to suit varying garments.
- Start with garments requiring lower temperatures and work your way through to items requiring higher temperatures.
- If you are unsure of the fabric content of a garment, test a small area such as a seam or inside hem section before ironing a visible area. Start with a low temperature and gradually increase the heat to find the best setting for ironing the garment.
- When reducing the temperature to iron sensitive fabrics, allow approximately 2 minutes for the iron to cool to the new setting.
- Pure woollen fabrics (100% wool) can be steam ironed with the temperature dial set to Wool. Use an ironing cloth to prevent shine marks on the fabric.
- Fabrics such as velour, wool, linen and silk are best ironed with an ironing cloth to prevent shine marks.
- Never iron areas of a garment where perspiration marks are visible, as the heat of the iron will fix the stains, making them permanent.

Ironing Chart

Fabric	Temperature Setting	Ironing Recommendation
Acrylic	•	Dry iron on wrong side.
Acetate	•	Dry iron on wrong side while still damp or use spray to dampen.
Silk	••	Iron on wrong side. Use an ironing cloth to prevent shine marks.
Nylon	••	Iron on wrong side while still damp or use spray to dampen.
Polyester	••	Iron on wrong side while still damp or use spray to dampen.
Rayon	••	Iron on wrong side of fabric.
Viscose	••	Mainly dry iron. Steam can be used under manufacturer's instructions.
Wool	••	Steam iron on wrong side or use an ironing cloth.
Wool Blends	••	Steam iron on wrong side or use an ironing cloth.
Cotton Blends	••	Check label and follow manufacturer's instructions. Use setting for the fibre requiring the lowest setting.
Corduroy	•••	Steam iron on wrong side or use an ironing cloth and brush to raise the pile.
Cotton	•••	Dry iron while still damp or use spray to dampen.
Linen	••• To MAX	Iron on wrong side or use an ironing cloth to prevent shine marks, especially with dark colours. Dry iron while still damp or use spray to dampen.
Denim	••• To MAX	Steam iron.

'Sunbeam' and 'Steam Pro' are registered trademarks of Sunbeam Corporation.

Designed in Italy. Made in China. Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet. Backed by Sunbeam's 2 Year Replacement Guarantee and National Service Network.

© Copyright. SUNBEAM CORPORATION LIMITED 2003.

(INCORPORATED IN N.S.W.) A.C.N. 000 006 771

Sunbeam Corporation is a division of GUD Holdings Ltd.

For more information or advice on this or any other Sunbeam appliance, visit **www.sunbeam.com.au** or contact the Sunbeam Consumer Service Line.

Australia 1800 025 059

New Zealand (09) 912 0747.



Consumer Hotline

Australia

1800 025 059

New Zealand

(09) 912 0747

www.sunbeam.com.au



is a registered Trademark of Sunbeam
Corporation Limited. ACN 000 006 771.

© Sunbeam Corporation Limited 2003.